

# Assembly Instructions For The Adirondack Chair

## Tools Needed:

Hammer For Light Tapping

## Parts List:

Seat Assembly (1)  
Back Assembly (1)  
Left Arm & Leg Assembly (1)  
Right Arm & Leg Assembly (1)

## Hardware:

1/4" x 2" Bolts (10)  
Allen Wrench (1)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Place the seat on a clean surface with the seating area facing up. Put the back assembly between the back legs behind the seat, aligning the predrilled holes in the legs with the threaded inserts on the bottom of the back assembly. Put a 2" bolt through the legs and turn into the inserts. Tighten with the Allen wrench.
- Step 3** Attach the arm & leg assemblies to the chair. Align the predrilled holes in the front leg with the inserts in the side of the seat. Put 2" bolts through the legs, turn into the inserts in the seat and tighten with the Allen wrench. (There is a right & left arm, the little brace belongs on the outside of the chair).
- Step 4** Attach the back of the arms to the back assembly. Put a 2" bolt through the predrilled hole in the arms & turn into the threaded insert in the side of the back assembly. If you have problems aligning the holes loosen the other bolts & push or pull the back to the proper position then retighten all bolts.

